


TO REPLACE BATTERY:




The 2 CR2032 coin batteries can be replaced by the following easy steps below:


Step 1:
Locate the small screw on top of Nathan's LED button & use a small screwdriver to unscrew it.



Step 2 & 3:
Open gently the top portion of the button & remove & replace both batteries with + positive mark facing down.



Use caution when opening, the top does not open fully. The top needs to stay at an angle.



Step 4:
Once new batteries are in place, close top portion and secure screw back in place.

